

Mr./Mrs/Ms: _____ Model: _____ Reg.No: _____

Invoice/Job no: _____ Odometer reading: _____ V.I.N: _____

| | | | | | | | | |
|--------------------|----|----|----|----|----|----|----|----|
| Service type: | A | B | A | B | A | B | A | B |
| Months/,000 miles: | 12 | 24 | 36 | 48 | 60 | 72 | 84 | 96 |

Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked *

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.



DEFENDER (Td5) (DIESEL MODELS 02 MY ON) MAINTENANCE CHECK SHEET

A B VEHICLE INTERIOR

1. Check condition and security of seats and seat belts
2. Check operation of all lamps, horns and warning indicators
3. Check operation of front/rear wipers and washers and condition of wiper blades
4. Check operation of handbrake
5. Check battery condition
6. Replace alarm handset batteries

VEHICLE EXTERIOR

7. Annual corrosion/cosmetic inspection - **Using annual corrosion inspection sheet, vehicles sold after 21/11/98**
8. Check headlamp and auxiliary lamp alignment
9. Remove road wheels
10. Check and adjust tyre pressures
LHF RHF RHR LHR Spare
11. Check and record tread depth
LHF RHF RHR LHR Spare
12. Inspect brake pads for wear, calipers for leaks and discs for condition
13. Inspect road wheel speed sensor electrical harness for damage **ABS only**
14. Renew fuel filter element
15. Drain fuel sedimenter
16. Refit road wheels to original hub position (Use anti-seize compound on spigot bore)
17. Visually check intercooler/radiator for external obstructions and fan blades for damage
18. Check ambient air pressure sensor for damage
19. Check operation and Lubricate door locks, hinges, door checks and bonnet catch

UNDER BONNET

20. Renew engine coolant
21. Replace Brake Fluid - **Also see recommendations**
22. Check cooling, intercooler and heating systems for leaks, hoses and oil pipes for security and condition. Top up as required
23. Renew air cleaner element and clean dump valve.
24. Check condition of ancillary driving belt
25. Renew ancillary driving belt
26. Check/top up brake, PAS and clutch fluid levels and screen washer reservoirs
27. Check/adjust steering box
28. Flush diesel intercooler element

UNDER VEHICLE

29. Renew engine oil
30. Renew centrifuge rotor

A B (UNDER VEHICLE)

31. Renew full flow filter
32. Renew manual gearbox oil
33. Renew transfer box oil
34. Check and top up transfer box oil
35. Renew front and rear axle oil
36. Check and top up front and rear axle oil
37. Lubricate propeller shaft universal/sliding joints
38. Check visually, brake servo hose, brake, fuel, clutch pipes and unions
39. Check for fluid leaks from power steering systems hydraulic pipes and unions for chafing and corrosion
40. Check for fluid leaks from Engine, Gearbox, Transfer box and Axles
41. Check exhaust system for leaks, security and damage
42. Check/tighten steering box and front and rear axle suspension fixings
43. Check steering rod ball joint fixings and condition of ball joints and dust covers
44. Check shock absorbers for leakage and damage
45. Check/tighten front and rear axle suspension link fixings, check condition of mounting rubbers
46. Check security of towing bracket
47. Check security of engine and transmission mounting rubbers
48. Carry out road or roller test (see WARNING over page)
49. Endorse service record
50. Report any unusual features of vehicle condition and additional work required

The maintenance items listed, are those recommended for vehicles operating under normal driving, road and climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions, off road driving or frequent towing of trailers. See overleaf for details

Service check completed and service portfolio book endorsed

Name: Signature: Date:

ARDUOUS DRIVING CONDITIONS - ADDITIONAL REQUIREMENTS

| Driving Condition | | | | | Maintenance Item | Task | Interval | ✓ |
|-------------------|---|---|---|---|---|------|------------------------------|---|
| V | W | X | . | Z | Engine oil | R | Every 10,000 km or 6 months | |
| . | W | . | Y | . | Air cleaner element - all models | S | Every 5,000 km or 3 months | |
| . | W | . | Y | . | Fuel Filter element - diesel models | R | Every 10,000 km or 6 months | |
| . | W | . | Y | . | Drain fuel sediment - diesel models | S | Every 10,000 km or 6 months | |
| . | . | X | . | . | Cooling hoses and connectors - all models | I | Every 10,000 km or 6 months | |
| . | W | X | Y | . | Ancillary drive belt - all models | I | Every 10,000 km or 6 months | |
| . | W | X | Y | Z | Wheel bearing grease - all models | S | Every 40,000 km or 24 months | |
| . | . | X | Y | Z | Gearbox oil - all models | R | Every 20,000 km or 12 months | |
| . | W | . | Y | Z | Front and rear brakes - all models | I | Every 5,000 km or 3 months | |
| . | W | . | Y | . | Suspension and steering components | I | Every 10,000 km or 6 months | |
| . | W | X | Y | . | Greasing points on propshaft | S | Every 10,000 km or 6 months | |

Driving Condition Code

V = Repeated short distance driving (e.g. up to 8 km), stop start driving or idling for long periods
W = Driving in dusty and/or sandy conditions
X = Driving in extremely hot conditions
Y = Driving on rough and/or muddy roads and/or wading
Z = Towing a trailer or driving in mountainous conditions

Task Codes

I = Inspection
R = Replace
S = Service

WARNING :

Two wheel roller tests must not be carried out. Four wheel roller tests must be restricted to 5 km/hour.

IMPORTANT

OIL CHANGE DIESEL ENGINES

If the vehicle is operated on fuel with a high sulphur content (over 1%) the oil change intervals must not exceed 10,000km.

IT IS RECOMMENDED THAT :

At 80,000 km intervals or every four years whichever is the earlier, all hydraulic brake caliper fluid seals, flexible brake hoses and brake servo filter should be renewed .
All working surfaces of the master cylinder and caliper cylinders should be examined and renewed where necessary .

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.

GLOSSARY

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 12,000 miles intervals, whichever occurs first.

Main Service (A) is applicable at 12 months/20,000 km, 36 months/60,000 km, 60 months/100,000 km, 84 months/140,000 km and so on.

Main Service (B) is applicable at 24 months/40,000 km, 48 months/80,000 km, 72 months/140,000 km, 96 months/160,000 km and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 100k(This indicates that this item is only applicable every 60 months/100,000km).

NOTE:The service required should be at the time or distance stated, **which ever occurs first.**